

# Thank you for purchasing the one and only **Guitdoorbell™**!

## Included:

- **Guitdoorbell™** with attached **3M™ Dual Lock™** Reclosable Fastener
- **Trophy Board** with attached **3M™ Dual Lock™** Reclosable Fastener
- **Striker Assembly** with attached **3M™ Dual Lock™** Reclosable Fastener
- **Pitch pipe** for tuning
- **Mounting Hardware**-screws/washers/wall anchors (4)

## Mounting the Trophy Board

1. Locate an inward swinging interior doorway for your new **Guitdoorbell™**!

2. While holding the **Trophy Board** (B) in the desired location, mark the position of each hole to be drilled by using the predrilled holes in the **Trophy Board** as a guide.

*(See image #1)*

**PLEASE NOTE:** The **Trophy Board** must be mounted no higher than 2 1/2 inches from the top of the door in order for the **Striker Assembly** to properly contact the strings of the **Guitdoorbell™**.

*(See image #1)*

3. Drill into the marked positions with a 1/8 inch drill bit. If mounting into a stud, the mounting screws are sufficient. If mounting into a stud is not possible, wall anchors must be used.

4. Align the predrilled holes in the **Trophy Board** with those drilled in the wall, and mount using the provided hardware. Tighten until snug.

*(See image #2)*

*With the **Trophy Board** correctly mounted, installing your **Guitdoorbell™** is a snap!*

## Installing the Guitdoorbell™

5. Place the **Guitdoorbell™** instrument into the installation position: parallel to the top of the door, with the strings facing down, and the tuning keys on the left.

*(See image #2)*

6. Align the **3M™ Dual Lock™** Reclosable Fastener on the side of the **Guitdoorbell™** with the **3M™ Dual Lock™** Reclosable Fastener on the **Trophy Board**. Press until a “click” is heard.

*(See image #2)*

7. Press the **3M™ Dual Lock™** Reclosable Fastener on the back of the **Guitdoorbell™**

firmly onto the **3M™ Dual Lock™** Reclosable Fastener on the L-bracket (C) using a slight upward motion until a “click” is heard. Gently tug the **Guitdoorbell™** to test that it is secure.

*(See image #2)*

**PLEASE NOTE:** Failure to mount as directed can lead to detachment of the **Guitdoorbell™** from the **Trophy Board**. Injury or damage could occur.

8. Place the **Striker Assembly** (D) vertically on the door so the **Plectrum** (E) aligns with the sound hole on the **Guitdoorbell™**. **Plectrum** should rest in the strings at a depth of 1/4 inch.

*(See images #3, #4)*

9. Mark the desired position of the **Striker Assembly** before attaching it to the door. Remove the adhesive protector from the **3M™ Dual Lock™** Reclosable Fastener, and attach the **Striker Assembly**. Use a level to adjust.

*(See images #3, #4)*

10. Twist the **Plectrum** so a slight angle is achieved. This will produce the best sound quality, and extend the life of the instrument.

*(See image #4)*

11. To remove the **Guitdoorbell™** from the **Trophy Board**, grasp the instrument body, and firmly pull down. **Do not pull on any other part of the instrument, as damage may occur.**

**SAFETY NOTE:** **3M™ Dual Lock™** Reclosable Fastener has a 1000 use life cycle. We recommend replacement before the life cycle is complete.

## Tuning and Maintenance

12. Use the pitch pipe (I) to tune the strings. The Classic **Guitdoorbell™** tuning is E7sus. Go to [www.guitdoorbell.com](http://www.guitdoorbell.com) for an audio sample, and additional tuning assistance.

*(See image #5)*

13. Re-string as needed for the best sound. A light gauge string (.012 to .053) is recommended. Please consult your local music store for further help with tuning and maintenance of your **Guitdoorbell™**.

[www.guitdoorbell.com](http://www.guitdoorbell.com)